



Fitting Instructions for The Strauss, Temple, Bovey, Barlow, Elite & Willington 1-piece Pitched Canopy with Brackets

STEP 1

- A: Mark centre-line onto door frame.
- B: Mark spirit level line – do not cover any weep holes.

STEP 2

- C: Mark centre-line on canopy soffit.
- D: 1st operative to offer soffit to wall marrying up with marks.

STEP 3

- E: 2nd operative to drill 6.5x120mm to each side through flange.
- F: Fix using 7.5x100mm concrete fixing with washer to take cover caps.

STEP 4

- G: Use spirit level to check canopy is level on projection.
- H: Pack between back of canopy and wall where required. Tighten/slacken fixing if necessary.

STEP 5

- I: Once canopy is all level, put fixings along the rest of flange at max 400mm (equal spacing).
 - J: Use spirit level to double check (loosen & pack if necessary)
- (please note if fixing to Frog Hall Brick ensure fixing goes into solid part of brickwork)

STEP 6

- K: Brackets (if using) to be drilled in centre of flat part of the leg/bracket at both ends.



STEP 7

L: Offer bracket to desired position, mark on the wall and underside of canopy through pre-drilled holes.

M: With brackets removed drill into brickwork, then fix using 100mm concrete screws, with washer to take cover caps.

N: Fix bracket up to canopy using 70mm wood screws with washer for cover caps.

STEP 8

O: Silicone mastic seal roof flange/wall and soffit/brickwork in appropriate colour.

P: Cover all visible screw heads with colour matching caps, or lead flash into brickwork and over flange (optional).



the
glazingshop

Tel: 01536 446395 Email: sales@theglazingshop.co.uk Web: www.theglazingshop.co.uk

Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX